

Insert Battery

Your Personal Television battery is in the box



Open the stand



Remove the back cover
by sliding it toward the
side buttons



Insert the battery



Replace the back cover